



ERROR CODES KAABO

- E2: Brake
- E4: Battery under voltage
- E6: Regulator problem
 - E7: Motor fault
 - E8: LCD fault
 - E9: Controller fault
- E10/11: Communication problem between controller and LCD
 - E12: BMS problem
 - E13: Light problem